




160 Cassell Road  
Harleysville, PA 19438  
484-991-8928  
www.veritas-medicalsolutions.com



The Quality Management of Veritas Medical  
Solutions is certified to ISO 9001:2015

# VeriShield® Mevion S250 Cyclotron Vault & 25" Bi-Parting Door

Auburn University - Proton Radiation Testing Facility  
Lot 4, Mark C. Smith Drive  
Huntsville, Alabama 35801  
United States of America



**CONFIDENTIALITY NOTICE** This message and any attachments contain confidential and proprietary information and are solely for the intended recipient. If you are not the intended recipient, any disclosure, copying, use, or distribution of information included in this message and any attachments is strictly prohibited. If you have received this communication in error, please notify us by replying via e-mail and immediately and permanently delete this message and any attachments. Thank you for your understanding.

**CONDITIONS OF USE** Attached files are for use in preparing planning, presentation, shop drawings, or related project specific material. Data in attached files is part of VERITAS' instruments of service and shall not be used, in whole or in part, by you or anyone else receiving this data through you or from you for any purpose other than preparing planning, presentation, shop drawings or related project specific material without express written consent from VERITAS. No sourcing, fabrication, installation, or construction is to be performed from the attached files. Attached files are not contract documents. Differences may exist between attached files and corresponding hard copy documents. VERITAS makes no representation regarding accuracy or completeness of attached files transmitted herein.

WHEN THIS DOCUMENT IT SUPPLIED TO EITHER OWNER OR CONTRACTOR, IN EITHER PAPER OR ELECTRONIC FORM, THE SUBSEQUENT USE OF THE INFORMATION CONTAINED ON THE DOCUMENT IS SUBJECT TO THE CONDITIONS OF THE AGREEMENT BETWEEN THE OWNER AND VERITAS AND TO VERITAS' COPYRIGHT AND OTHER SUCH RIGHTS IN THIS DOCUMENT. CONTRACTOR MAY MAKE ELECTRONIC FILES OF THIS DOCUMENT AVAILABLE TO SUBCONTRACTORS, SUBJECT TO THIS CONDITION OF USE, SOLELY AS A CONVENIENCE TO SUCH SUBCONTRACTORS IN THEIR PREPARATION OF SHOP DRAWINGS. THE PROVISION OF THIS DOCUMENT BY VERITAS SHALL NOT MAKE VERITAS RESPONSIBLE IN ANY WAY FOR ANY ASPECT OF THE SUBCONTRACTOR'S SHOP DRAWINGS, NOR RELIEVE SUBCONTRACTORS FROM FULL RESPONSIBILITY FOR PREPARATION OF THEIR REQUIRED SHOP DRAWINGS.

DRAWING INDEX			
Drawing Number	Drawing Title	Current Drawing Set / Milestone	Current Drawing Date
X-000	COVER SHEET	Review Set (DD 90%)	21 March 2025
X-100	CONTEXT PLAN	Review Set (DD 90%)	21 March 2025
X-110	WALL SHIELDING PLAN	Review Set (DD 90%)	21 March 2025
X-130	CEILING SHIELDING PLAN	Review Set (DD 90%)	21 March 2025
X-300	SECTIONS	Review Set (DD 90%)	21 March 2025
X-301	SECTIONS	Review Set (DD 90%)	21 March 2025
XS-001	GENERAL STRUCTURAL NOTES	Review Set (DD 90%)	21 March 2025
XS-100	PRELIMINARY LOADING PLAN	Review Set (DD 90%)	21 March 2025
XS-110	WALL REINFORCING PLAN	Review Set (DD 90%)	21 March 2025
XS-200	VAULT FRAMING PLAN	Review Set (DD 90%)	21 March 2025
XS-210	BEARING PLATE PLAN	Review Set (DD 90%)	21 March 2025
XS-300	STRUCTURAL DETAILS	Review Set (DD 90%)	21 March 2025
XS-500	STEEL DETAILS	Review Set (DD 90%)	21 March 2025
XS-515	STEEL DETAILS FRAMED DOOR OPENING	Review Set (DD 90%)	21 March 2025

SUPPORT DOCUMENT INDEX			
Drawing Number	Drawing Title	Current Drawing Set / Milestone	Current Drawing Date
BP-001	DOOR POWER & CONTROL DIAGRAM (BI-PART)	Provided with Layout Set	05 February 2025
BP-002	DOOR DEVICE DETAILS (BI-PART)	Provided with Layout Set	05 February 2025

REVIEW SET COORDINATION NOTES:			
COORDINATION ITEM:	PARTY:	COMMENT / ACTION ITEM:	
DOOR CONTROLS	(CLIENT/REP)	REVIEW:	DOOR POWER & CONTROL DIAGRAM PRELIMINARY DOOR CONTROL LOCATIONS PROVIDED WITH LAYOUT SET SEE SHEET: X-100
		COORDINATE:	FINAL DOOR CONTROL LOCATIONS WITH VERITAS
GENERAL MEP	(CLIENT/ REP)	NOTES:	INITIAL SERVICE ROUTES CAPTURED IN LAYOUT SET DISCUSSED DURING COORDINATION CALL ON 01/31/2025 (4) 4" I.D. SERVICE SLEEVES + TEST SLEEVE PROVIDED IN LAYOUT SET FOR REVIEW.  REVIEW: NEW SERVICE ROUTES DISCUSS DURING RECENT COORDINATION CALL ON 03/18/2025 SEE SHEETS (X-110) & (XS-110) FOR PLACEMENT IN PLAN. SEE SECTIONS ON SHEET (X-300) FOR SLEEVE HEIGHTS. NEW SLEEVE QUANTITIES & NOTES: (5) 5" I.D. SLEEVES RESTING ON COURSE 29 IN [W1] WALL (5) 4" I.D. SLEEVES RESTING ON COURSE 26 IN [W1] WALL (1) 4" I.D. SLEEVE RESTING ON COURSE 29 IN [W7] WALL - (SPLIT SYSTEM) (1) 4" I.D. SLEEVE MID WALL ON DOUBLE 45 DEGREE ANGLE IN [W7] WALL - (TESTING PORT) LOW END ON EXTERIOR SIDE - PLEASE IDENTIFY APPROXIMATE DESIRED HEIGHT HIGH END ON INTERIOR SIDE (1) 4" I.D. SLEEVE RESTING ON COURSE 29 IN [W8] WALL
APPROVALS	(CLIENT/REP)	NOTE:	THIS REVIEW SET TO SERVE AS THE (DD 90%) DESIGN DEVELOPMENT DELIVERABLE OF THE VERITAS SCOPE OF WORK FOR THE DESIGN ONLY CONTRACT.  PLEASE PROVIDE FEEDBACK FOR ANY CHANGES REQUIRED FOR FINAL APPROVAL.  IF NO ADDITIONAL CHANGES ARE REQUIRED, PLEASE EXPRESS WRITTEN APPROVAL THAT THE DESIGN SOLUTION IS ACCEPTABLE AND THE TEAM IS READY TO ADVANCE TO THE FULL BUILD & CD (CONSTRUCTION DOC.) PHASE, UNDER SEPARATE CONTRACT.

SEAL



## CONDITIONS OF USE

WHEN THIS DOCUMENT IS SUPPLIED TO EITHER OWNER OR CONTRACTOR, IN EITHER PAPER OR ELECTRONIC FORM, THE SUBSEQUENT USE OF THE INFORMATION CONTAINED ON THE DOCUMENT IS SUBJECT TO THE CONDITIONS OF THE AGREEMENT BETWEEN THE OWNER AND VERITAS AND TO VERITAS' COPYRIGHT AND OTHER SUCH RIGHTS IN THIS DOCUMENT. CONTRACTOR MAY MAKE ELECTRONIC FILES OF THIS DOCUMENT AVAILABLE TO SUBCONTRACTORS IN THEIR PREPARATION OF SHOP DRAWINGS. THE PROVISION OF THIS DOCUMENT BY VERITAS SHALL NOT MAKE VERITAS RESPONSIBLE IN ANY WAY FOR ANY ASPECT OF THE SUBCONTRACTORS SHOP DRAWINGS, NOR RELIEVE SUBCONTRACTORS FROM FULL RESPONSIBILITY FOR PREPARATION OF THEIR REQUIRED SHOP DRAWINGS.

VeriShield Mevion S250 Cyclotron Vault & 25" Bi-Parting Door  
Auburn University - Proton Radiation Testing Facility  
Lot 4, Mark C. Smith Drive  
Huntsville, Alabama 35801  
United States of America

## DRAWING ISSUE LOG

#	ISSUE TITLE	Date
	Layout Set	02/05/2025
	Review Set	03/21/2025

## VERITAS PROJECT TEAM

SALES REP:	Greg Shearer
PHYSICIST:	El Hassane Bentefour
DESIGNER:	Jay DiRaimondo
PROJECT MANAGER:	Susan Heid

## VERITAS PROJECT INFORMATION

PROJECT #	24-136-5195
PROSPECT #	5195-01
PHYSICS REPORT:	
SHIELDED DOOR(S):	BP25 (3060-501)
MACHINE:	Mevion S250
MACHINE ENERGY:	

## DRAWING TITLE

COVER SHEET

## DRAWING NUMBER

X-000

# Review Set - 03/21/2025


NOT FOR CONSTRUCTION

VERITAS PHYSICS & DESIGN ONLY ESTIMATE # 5195-01  
VERITAS PHYSICS & DESIGN ONLY PROJECT# 24-136-5195

VERITAS FULL BUILD ESTIMATE # xxxx-xx  
VERITAS FULL BUILD PROJECT# xx-xxx-xxxx

PRELIMINARY - NOT FOR CONSTRUCTION






A technical drawing of a door assembly, likely a fire door, showing its internal components and mounting. The drawing is a cross-section view. A yellow vertical band represents the door's core. A blue L-shaped frame represents the door frame. A black rectangular component, likely a fire-rated hinge or latch, is mounted on the door. Red lines with arrows point from labels to specific parts: A points to the top hinge area, D2 points to the top hinge pin, HAND CRANK points to a handle on the door, C points to the top hinge plate, F points to the bottom hinge area, D1 points to the bottom hinge pin, and E1 / E2 points to the bottom hinge plate. The door is shown in a closed position, with the handle on the right side.

A	DOOR CONTROL BINET. PREFERABLY LOCATED WITHIN SIGHT OF DOORS
C	[HIMJ] TOUCH SCREEN - LOCATE AT / NEAR TREATMENT ROOM ENTRANCE ( <u>OUTSIDE OF SAFETY SENSOR FIELD</u> )
D1	[PBOJ] PUSH BUTTON OP. STATION - LOCATE NEAR CONTROL DESK - IN CONTROL ROOM.
D2	[PBOJ] IN ROOM - KEYED, AWAY FROM DOOR, NOT IN PRIMARY BEAM PATH
E1, E2, & F	INTERLOCK SWITCHES & SAFETY SENSORS LOCATED IN DOOR CAVEY & FINISHED DOOR OPENING.
H	HAND CRANK CAN BE LOCATED ON EITHER POST. ACCESS IS REQUIRED, RECOMMENDED: 2'-6" x 7'-0" DOOR (BY OTHERS)

# X-100

PRELIMINARY - NOT FOR CONSTRUCTION



1 Wall Shielding Plan  
3/8" = 1'-0"

Wall Shield Schedule		
Shielding Region P1 - P12	Type - Layers	Comments
D1	V300 - 5	Shielding in Door Shell
Te	V220 - 3	Transport Opening Infill - 3 Exterior Layers
Ti	V220 - 6	Transport Opening Infill - 6 Interior Layers
W1	V220 - 9 Bearing	
W2	V220 - 9	
W2a	V220 - 6	Transport Opening Laps
W3	V220 - 15 Bearing	
W4	V220 - 8 Bearing	
W5	V220 - 9	
W6	V220 - 6	
W7	V220 - 8 Bearing	
W8	V220 - 5	
W9	V220 - 3	
W10	V220 - 3	
W11	V220 - 3	
W12	V220 - 3	
W13	V220 - 3	

SLIDING & BI-PARTING DOOR CAVITY NOTES:

FLOOR SLAB CONDITIONS:

- SLAB REINFORCING / FOUNDATION WORK BY OTHERS  
REFER TO SHEET XS-100 FOR DOOR LOAD INFORMATION.
- RECOMMENDED SLAB THICKNESS BELOW DOOR BASE PLATES: 24" (610mm)  
REQUIRED MINIMUM SLAB BELOW DOOR BASE PLATES: 18" (457mm)  
TYPICAL MIN. DOOR ANCHOR EMBED: 12" (305mm)  
  
\* PLEASE COORDINATE LOCATION SLAB REINFORCING OUTSIDE OF BASE PLATE  
FOOTPRINT TO PREVENT DAMAGE TO REBAR OR DELAYS TO INSTALLATION.
- FINISHED TREATMENT LEVEL FLOOR SLAB CONDITION MUST BE FLAT / LEVEL WITH A TOLERANCE NOT TO  
EXCEED 1/8" OVERALL WITHIN THE DOOR CAVITY.
- DOOR FINISH CAVITY BY OTHERS.  
MINIMUM CAVITY SIZE REQUIREMENTS VARY PER DOOR TYPE & MODEL.  
ACCESS IS REQUIRED ON ONE SIDE FOR HAND CRANK & SERVICE.  
RECOMMENDATION: A 2'-6" (762mm) x 7'-0" (2.134mm) ACCESS DOOR.  
ACCESS IS REQUIRED ABOVE CEILING ALONG THE FRONT OF DOOR SUPPORT BEAM.  
RECOMMENDATION: UTILIZE REMOVABLE CEILING TILES (ACT) OR PROVIDE ACCESS PANELS

SEAL

**veritas**  
Medical Solutions  
160 CASSELL RD.  
HARLEYSVILLE, PA 19438  
(484) 991-8928

CONDITIONS OF USE

WHEN THIS DOCUMENT IS SUPPLIED TO EITHER OWNER OR CONTRACTOR, IN EITHER PAPER OR ELECTRONIC FORM, THE SUBSEQUENT USE OF THE INFORMATION CONTAINED ON THE DOCUMENT IS SUBJECT TO THE CONDITIONS OF THE AGREEMENT BETWEEN THE OWNER AND VERITAS AND TO VERITAS COPYRIGHT AND OTHER SUCH RIGHTS IN THIS DOCUMENT. CONTRACTOR MAY MAKE ELECTRONIC FILES OF THIS DOCUMENT AVAILABLE TO SUBCONTRACTORS IN THEIR PREPARATION OF SHOP DRAWINGS. THE PROVISION OF THIS DOCUMENT BY VERITAS SHALL NOT MAKE VERITAS RESPONSIBLE IN ANY WAY FOR ANY ASPECT OF THE SUBCONTRACTORS SHOP DRAWINGS, NOR RELIEVE SUBCONTRACTORS FROM FULL RESPONSIBILITY FOR PREPARATION OF THEIR REQUIRED SHOP DRAWINGS.


VeriShield Mevion S250 Cyclotron Vault & 25" Bi-Parting Door  
Auburn University - Proton Radiation Testing Facility  
Lot 4, Mark C. Smith Drive  
Huntsville, Alabama 35801  
United States of America

DRAWING ISSUE LOG		
#	ISSUE TITLE	Date
1	Layout Set	02/05/2025
2	Review Set	03/21/2025

VERITAS PROJECT TEAM	
SALES REP:	Greg Shearer
PHYSICIST:	El Hassane Bentefour
DESIGNER:	Jay DiRaimondo
PROJECT MANAGER:	Susan Heid
VERITAS PROJECT INFORMATION	
PROJECT #	24-136-5195
PROSPECT #	5195-01
PHYSICS REPORT:	
SHIELDED DOOR(S):	BP25 (3060-501)
MACHINE:	Mevion S250
MACHINE ENERGY:	
DRAWING TITLE	
WALL SHIELDING PLAN	
DRAWING NUMBER	
X-110	

PRELIMINARY - NOT FOR CONSTRUCTION





Wall Shield Schedule		
Shielding Region P1 - P12	Type - Layers	Comments
D1	V300 - 5	Shielding in Door Shell
Te	V220 - 3	Transport Opening Infill - 3 Exterior Layers
Ti	V220 - 6	Transport Opening Infill - 6 Interior Layers
W1	V220 - 9 Bearing	
W2	V220 - 9	
W2a	V220 - 6	Transport Opening Laps
W3	V220 - 15 Bearing	
W4	V220 - 8 Bearing	
W5	V220 - 9	
W6	V220 - 6	
W7	V220 - 8 Bearing	
W8	V220 - 5	
W9	V220 - 3	
W10	V220 - 3	
W11	V220 - 3	
W12	V220 - 3	
W13	V220 - 3	

Ceiling Shield Schedule		
Shielding Region C1-3 & L1-2	Type - Thickness	Comments
C1	V220 - 6	

SEAL

180 CASSELL RD.  
HARLEYSVILLE, PA 19438  
(484) 991-8928

CONDITIONS OF USE

WHEN THIS DOCUMENT IS SUPPLIED TO EITHER OWNER OR CONTRACTOR, IN EITHER PAPER OR ELECTRONIC FORM, THE SUBSEQUENT USE OF THE INFORMATION CONTAINED ON THE DOCUMENT IS SUBJECT TO THE CONDITIONS OF THE AGREEMENT BETWEEN THE OWNER AND VERITAS AND TO VERITAS COPYRIGHT AND OTHER SUCH RIGHTS IN THIS DOCUMENT. CONTRACTOR MAY MAKE ELECTRONIC FILES OF THIS DOCUMENT AVAILABLE TO SUBCONTRACTORS IN THEIR PREPARATION OF SHOP DRAWINGS. THE PROVISION OF THIS DOCUMENT BY VERITAS SHALL NOT MAKE VERITAS RESPONSIBLE IN ANY WAY FOR ANY ASPECT OF THE SUBCONTRACTORS SHOP DRAWINGS, NOR RELIEVE SUBCONTRACTORS FROM FULL RESPONSIBILITY FOR PREPARATION OF THEIR REQUIRED SHOP DRAWINGS.

VeriShield Mevion S250 Cyclotron Vault & 25" Bi-Parting Door  
Auburn University - Proton Radiation Testing Facility  
Lot 4, Mark C. Smith Drive  
Huntsville, Alabama 35801  
United States of America

DRAWING ISSUE LOG		
#	ISSUE TITLE	Date
	Layout Set	02/05/2025
	Review Set	03/21/2025

VERITAS PROJECT TEAM	
SALES REP:	Greg Shearer
PHYSICIST:	El Hassane Bentefour
DESIGNER:	Jay DiRaimondo
PROJECT MANAGER:	Susan Heid

VERITAS PROJECT INFORMATION	
PROJECT #	24-136-5195
PROSPECT #	5195-01
PHYSICS REPORT:	
SHIELDED DOOR(S):	BP25 (3060-501)
MACHINE:	Mevion S250
MACHINE ENERGY:	

DRAWING TITLE


CEILING SHIELDING PLAN

DRAWING NUMBER


X-130

1 Ceiling Shielding Plan  
3/8" = 1'-0"

1 Section Through Isocenter 2  
3/8" = 1'-0"



2 Section Through Isocenter  
3/8" = 1'-0"



Wall Shield Schedule		
Shielding Region P1 - P12	Type - Layers	Comments
D1	V300 - 5	Shielding in Door Shell
Te	V220 - 3	Transport Opening Infill - 3 Exterior Layers
Ti	V220 - 6	Transport Opening Infill - 6 Interior Layers
W1	V220 - 9 Bearing	
W2	V220 - 9	
W2a	V220 - 6	Transport Opening Laps
W3	V220 - 15 Bearing	
W4	V220 - 8 Bearing	
W5	V220 - 9	
W6	V220 - 6	
W7	V220 - 8 Bearing	
W8	V220 - 5	
W9	V220 - 3	
W10	V220 - 3	
W11	V220 - 3	
W12	V220 - 3	
W13	V220 - 3	

Ceiling Shield Schedule		
Shielding Region C1-3 & L1-2	Type - Thickness	Comments
C1	V220 - 6	

SEAL



CONDITIONS OF USE

WHEN THIS DOCUMENT IS SUPPLIED TO EITHER OWNER OR CONTRACTOR, IN EITHER PAPER OR ELECTRONIC FORM, THE SUBSEQUENT USE OF THE INFORMATION CONTAINED ON THE DOCUMENT IS SUBJECT TO THE CONDITIONS OF THE AGREEMENT BETWEEN THE OWNER AND VERITAS AND TO VERITAS COPYRIGHT AND OTHER SUCH RIGHTS IN THIS DOCUMENT. CONTRACTOR MAY MAKE ELECTRONIC FILES OF THIS DOCUMENT AVAILABLE TO SUBCONTRACTORS IN THEIR PREPARATION OF SHOP DRAWINGS. THE PROVISION OF THIS DOCUMENT BY VERITAS SHALL NOT MAKE VERITAS RESPONSIBLE IN ANY WAY FOR ANY ASPECT OF THE SUBCONTRACTORS SHOP DRAWINGS, NOR RELIEVE SUBCONTRACTORS FROM FULL RESPONSIBILITY FOR PREPARATION OF THEIR REQUIRED SHOP DRAWINGS.

VeriShield Mevion S250 Cyclotron Vault & 25" Bi-Parting Door  
Auburn University - Proton Radiation Testing Facility  
Lot 4, Mark C. Smith Drive  
Huntsville, Alabama 35801  
United States of America

DRAWING ISSUE LOG

#	ISSUE TITLE	Date
1	Layout Set	02/05/2025
2	Review Set	03/21/2025

VERITAS PROJECT TEAM

SALES REP:	Greg Shearer
PHYSICIST:	El Hassane Bentefour
DESIGNER:	Jay DiRaimondo
PROJECT MANAGER:	Susan Heid

VERITAS PROJECT INFORMATION

PROJECT #	24-136-5195
PROSPECT #	5195-01
PHYSICS REPORT:	
SHIELDED DOOR(S):	BP25 (3060-501)
MACHINE:	Mevion S250
MACHINE ENERGY:	

DRAWING TITLE



SECTIONS

DRAWING NUMBER

X-300

PRELIMINARY - NOT FOR CONSTRUCTION





Ceiling Shield Schedule		
Shielding Region C1-3 & L1-2	Type - Thickness	Comments
C1	V220 - 6	

The image shows the top portion of a document. On the left is the Seal of the State of Maryland, featuring a shield with a ship, a star, and a banner, surrounded by the words 'SEAL OF THE STATE OF MARYLAND'. To the right of the seal is the logo for 'veritas Medical Solutions'. The word 'veritas' is in a large, bold, blue sans-serif font, with a small orange dot above the 'i'. Below it, 'Medical Solutions' is written in a smaller, blue sans-serif font. Underneath the logo is the address: '160 CASSELL RD.', 'HARLEVILLE, PA 17438', and '(484) 991-8928'. A decorative wavy line separates the header from the main body of the document.

VeriShield Mevion S250 Cyclotron Vault & 25" Bi-Parting Door  
Auburn University - Proton Radiation Testing Facility  
Lot 4, Mark C. Smith Drive  
Huntsville, Alabama 35801  
United States of America

DRAWING ISSUE LOG		
#	ISSUE TITLE	Date
	Layout Set	02/05/2025
	Review Set	03/21/2025

VERITAS PROJECT TEAM	
SALES REP:	Greg Shearer
PHYSICIST:	El Hassane Bentefour
DESIGNER:	Jay DiRaimondo
PROJECT MANAGER:	Susan Heid

VERITAS PROJECT INFORMATION	
PROJECT #	24-136-5195
PROSPECT #	5195-01
PHYSICS REPORT:	
SHIELDED DOOR(S):	BP25 (3060-501)
MACHINE:	Mevion S250
MACHINE ENERGY:	

DRAWING TITLE

## SECTIONS

	DRAWING NUMBER
--	----------------


X-301

PRELIMINARY - NOT FOR CONSTRUCTION









Loading Schedule - Wall Shielding...		
Shielding Region P1 - P12	Type - Layers	Wall Loading (PLF)
Te	V220 - 3	
Ti	V220 - 6	
W1	V220 - 9 Bearing	16430
W2	V220 - 9	16430
W2a	V220 - 6	
W3	V220 - 15 Bearing	27460
W4	V220 - 8 Bearing	14630
W5	V220 - 9	16430
W6	V220 - 6	10940
W7	V220 - 8 Bearing	14630
W8	V220 - 5	7190
W9	V220 - 3	2460
W10	V220 - 3	2460
W11	V220 - 3	2460
W12	V220 - 3	2460
W13	V220 - 3	2460

PARTIAL INFILL, SEE [W2] FOR FULL WALL LOAD  
PARTIAL INFILL, SEE [W2] FOR FULL WALL LOAD  
PARTIAL INFILL, SEE [W2] FOR FULL WALL LOAD

VAULT LOADING PLAN NOTES:

- ALL LOADS SHOWN ARE PRELIMINARY & BASED ON DESIGN OF CURRENT MILESTONE (LAYOUT SET OR REVIEW SET).  
  
FINAL LOADS TO BE PROVIDED IN THE CONSTRUCTION SET.  
ANY ADJUSTMENTS TO DESIGN MAY EFFECT LOADING.

LOADS PROVIDED HAVE BEEN UPDATED FOR THE CURRENT REVIEW SET  
PER VERITAS' STRUCTURAL CONSULTANT REVIEW.  
THE LOADING INFORMATION IS STILL PRELIMINARY / NOT FINALIZED.

- LOADS FROM UTILITY PENETRATION SHIELDING & SUPPORT:  
N/A NO UTILITY PENETRATIONS TO BE SUPPORTED THROUGH-WALL SLEEVES ONLY
- WALL & CEILING SHIELDING LOADS INCLUDE A 10% INCREASE AS A SAFETY FACTOR.
- SLIDING DOOR PRODUCTS GENERATE POINT LOADS AT THE DOOR FRAME POSTS. REFER TO PLAN FOR LOADING INFORMATION. REINFORCE THE SLAB BELOW POSTS APPROPRIATELY.

SWING DOOR PRODUCTS GENERATE POINT LOADS AT THE HINGE POINT. REFER TO PLAN FOR LOADING INFORMATION. REINFORCE THE SLAB BELOW LOWER HINGE PLATE APPROPRIATELY.  
N/A DOOR TYPE NOT IN SCOPE

- LOADS APPLIED TO FRAMING DESIGN ACCOUNTS FOR VERITAS SCOPE ITEMS ONLY (BEAMS, SUPPLEMENTAL SHIELDING, CEILING SHIELDING, ETC.).  
  
ANY ADDITIONAL LOADS THAT WOULD BE APPLIED TO FRAMING MUST BE PROVIDED FOR REVIEW / APPROVAL AS THE LOADS MAY REQUIRE RE-SIZING OF BEAMS, INCUR ADDITIONAL COSTS, AND MAY POTENTIALLY PUSH SCHEDULE IF A CHANGE IS REQUIRED LATE IN VERITAS' DESIGN PROCESS.

UNLESS NOTED OTHERWISE, TOTAL ACCEPTABLE MACHINE EQUIPMENT LOADS (POST / BRACKET MOUNTED TO BEAMS) WITHOUT THE NEED OF REVIEW / APPROVAL: MAX. 100 lbs (45.36 kg) PER INSTANCE, TYP.

- POINT LOADS ARE NOT INCLUDED IN THE LINEAR LOADS SHOWN. THEY ARE IN ADDITION TO THE LINEAR LOADS.

SEAL



CONDITIONS OF USE

WHEN THIS DOCUMENT IS SUPPLIED TO EITHER OWNER OR CONTRACTOR, IN EITHER PAPER OR ELECTRONIC FORM, THE SUBSEQUENT USE OF THE INFORMATION CONTAINED ON THE DOCUMENT IS SUBJECT TO THE CONDITIONS OF THE AGREEMENT BETWEEN THE OWNER AND VERITAS AND TO VERITAS' COPYRIGHT AND OTHER SUCH RIGHTS IN THIS DOCUMENT. CONTRACTOR MAY MAKE ELECTRONIC FILES OF THIS DOCUMENT AVAILABLE TO SUBCONTRACTORS IN THEIR PREPARATION OF SHOP DRAWINGS. THE PROVISION OF THIS DOCUMENT BY VERITAS SHALL NOT MAKE VERITAS RESPONSIBLE IN ANY WAY FOR ANY ASPECT OF THE SUBCONTRACTORS SHOP DRAWINGS, NOR RELIEVE SUBCONTRACTORS FROM FULL RESPONSIBILITY FOR PREPARATION OF THEIR REQUIRED SHOP DRAWINGS.

Pennoni Associates Inc.  
81 Highland Ave., Suite 230  
Bethlehem, PA 18017  
PAI Job No. W0507 25 003

RESPONSIBILITY IS LIMITED TO THE STRUCTURAL DESIGN OF THE SHIELDING SYSTEM PREPARED BY PENNONI ASSOCIATES, INC.

VeriShield Mevion S250 Cyclotron Vault & 25" Bi-Parting Door  
Auburn University - Proton Radiation Testing Facility  
Lot 4, Mark C. Smith Drive  
Huntsville, Alabama 35801  
United States of America

DRAWING ISSUE LOG

#	ISSUE TITLE	Date
1	Layout Set	02/05/2025
2	Review Set	03/21/2025

VERITAS PROJECT TEAM

SALES REP:	Greg Shearer
PHYSICIST:	El Hassane Bentefour
DESIGNER:	Jay DiRaimondo
PROJECT MANAGER:	Susan Heid

VERITAS PROJECT INFORMATION

PROJECT #	24-136-5195
PROSPECT #	5195-01
PHYSICS REPORT:	
SHIELDED DOOR(S):	BP25 (3060-501)
MACHINE:	Mevion S250
MACHINE ENERGY:	

DRAWING TITLE


PRELIMINARY  
LOADING PLAN

DRAWING NUMBER

XS-100

PRELIMINARY - NOT FOR CONSTRUCTION






REINFORCING PLAN NOTES:

- 1) HORIZONTAL & VERTICAL CELLS TO UTILIZE VERISHIELD GROUT OF COMPARABLE DENSITY & ATTENUATION PROPERTIES OF THE WALL SHIELDING THEY OCCUPY IN ORDER TO MAINTAIN APPROPRIATE SHIELDING BARRIERS PER THE PHYSICS REQUIREMENTS.
- ALL GROUT CELLS & FILL REGIONS TO BE: V220 DENSITY  
ALL HALF BLOCK TO BE: V220 DENSITY  
LEVELING BEDS LESS THAN 1/4" [6mm] CAN BE: STANDARD GROUT
- 2) HORIZONTAL & VERTICAL REBAR TO BE: #6 [3/4"], UNLESS NOTED OTHERWISE
- 6" MIN. [152 mm] EMBED INTO (E) CONCRETE, WHERE APPLICABLE  
w/ HILTI HIT-HY200 (USA) OR HIT-RE500 (INTERNATIONAL) INJECTION ADHESIVE, OR APPROVED EQUIVALENT.


- 3) WALL TIES AND DIAPHRAGM STRAPS PROVIDE ADDITIONAL LATERAL REINFORCING TO THE SYSTEM.
- THESE ITEMS CAN BE FOUND ON THE BEARING PLATE PLAN(S), AS THEY ARE LOCATED AT THE BOTTOM OF STEEL BEAMS.

SYMBOL	VERTICAL CELL NOTE	HEIGHT	QTY
	SLAB THRU COURSE 19	8.02'	13
	SLAB THRU COURSE 33	13.94'	30
	SLAB THRU COURSE 42	17.73'	164

Vertical Cell Schedule  
3/4" = 1'-0"



3 CORNER REINFORCING - PLAN DETAIL  
1" = 1'-0"



2 TYPICAL REBAR EMBED DETAIL  
1" = 1'-0"

SEAL

160 CASSELL RD.  
HARLEYSVILLE, PA 19438  
(484) 991-8928

CONDITIONS OF USE

WHEN THIS DOCUMENT IS SUPPLIED TO EITHER OWNER OR CONTRACTOR, IN EITHER PAPER OR ELECTRONIC FORM, THE SUBSEQUENT USE OF THE INFORMATION CONTAINED ON THE DOCUMENT IS SUBJECT TO THE CONDITIONS OF THE AGREEMENT BETWEEN THE OWNER AND VERITAS AND TO VERITAS COPYRIGHT AND OTHER SUCH RIGHTS IN THIS DOCUMENT. CONTRACTOR MAY MAKE ELECTRONIC FILES OF THIS DOCUMENT AVAILABLE TO SUBCONTRACTORS IN THEIR PREPARATION OF SHOP DRAWINGS. THE PROVISION OF THIS DOCUMENT BY VERITAS SHALL NOT MAKE VERITAS RESPONSIBLE IN ANY WAY FOR ANY ASPECT OF THE SUBCONTRACTORS SHOP DRAWINGS, NOR RELIEVE SUBCONTRACTORS FROM FULL RESPONSIBILITY FOR PREPARATION OF THEIR REQUIRED SHOP DRAWINGS.

Pennoni Associates Inc.  
81 Highland Ave., Suite 230  
Bethlehem, PA 18017  
PAI Job No. VM0507 25 003

RESPONSIBILITY IS LIMITED TO THE STRUCTURAL DESIGN OF THE SHIELDING SYSTEM PREPARED BY PENNONI ASSOCIATES, INC.

VeriShield Mevion S250 Cyclotron Vault & 25" Bi-Parting Door  
Auburn University - Proton Radiation Testing Facility  
Lot 4, Mark C. Smith Drive  
Huntsville, Alabama 35801  
United States of America

DRAWING ISSUE LOG

#	ISSUE TITLE	Date
1	Review Set	03/21/2025

VERITAS PROJECT TEAM

SALES REP:	Greg Shearer
PHYSICIST:	El Hassane Bentefour
DESIGNER:	Jay DiRaimondo
PROJECT MANAGER:	Susan Heid

VERITAS PROJECT INFORMATION

PROJECT #	24-136-5195
PROSPECT #	5195-01
PHYSICS REPORT:	
SHIELDED DOOR(S):	BP25 (3060-501)
MACHINE:	Mevion S250
MACHINE ENERGY:	

DRAWING TITLE

WALL  
REINFORCING  
PLAN

DRAWING NUMBER

XS-110


PRELIMINARY - NOT FOR CONSTRUCTION








1 Bearing Plate Plan  
3/8" = 1'-0"



Bearing Plate Schedule (XS-210)				
Mark	Plate Thickness	BP Width	BP Length	Count
BP10-12	3/4"	10"	12"	1
BP10-15	3/4"	10"	15"	1
BP10-26	3/4"	10"	26"	2
BP10-28	3/4"	10"	28"	28
HP10-15	1"	10"	15"	2

BEARING PLATE NOTES:

- SHOP WELD 4" [101mm] LONG, 5/8" [15.875mm] DIA. HEADED ANCHOR STUDS TO BEARING PLATES.
- REFER TO STRUCTURAL DETAILS FOR SPACING & WELD REQUIREMENTS.
- TOP OF HEADER PLATES [HPxx-xx] TO BE SET LOWER THAN T.O. BEARING PLATE ELEVATION BY THE THICKNESS OF THE HEADER BEAM FLANGE DIMENSION.



2 BEARING DETAILS  
1" = 1'-0"

Diaphragm Strap & Wall Tie Schedule (XS-210)				
Mark	Plate Thickness	Plate Width	Plate Length	Count
DS-38	5/8"	8"	38"	33
EP-10	1"	10"	10"	7
WT-38	1"	5"	38"	2
WT-50	1"	5"	50"	3
WT-53	1"	5"	53"	2

WALL TIE & DIAPHRAGM STRAP NOTES:

- REFER TO THE STRUCTURAL DETAILS FOR FIELD WELD REQUIREMENTS.

SEAL



CONDITIONS OF USE

WHEN THIS DOCUMENT IS SUPPLIED TO EITHER OWNER OR CONTRACTOR, IN EITHER PAPER OR ELECTRONIC FORM, THE SUBSEQUENT USE OF THE INFORMATION CONTAINED ON THE DOCUMENT IS SUBJECT TO THE CONDITIONS OF THE AGREEMENT BETWEEN THE OWNER AND VERITAS AND TO VERITAS COPYRIGHT AND OTHER SUCH RIGHTS IN THIS DOCUMENT. CONTRACTOR MAY MAKE ELECTRONIC FILES OF THIS DOCUMENT AVAILABLE TO SUBCONTRACTORS IN THEIR PREPARATION OF SHOP DRAWINGS. THE PROVISION OF THIS DOCUMENT BY VERITAS SHALL NOT MAKE VERITAS RESPONSIBLE IN ANY WAY FOR ANY ASPECT OF THE SUBCONTRACTORS SHOP DRAWINGS, NOR RELIEVE SUBCONTRACTORS FROM FULL RESPONSIBILITY FOR PREPARATION OF THEIR REQUIRED SHOP DRAWINGS.

Pennoni Associates Inc.  
81 Highland Ave., Suite 230  
Bethlehem, PA 18017  
PAI Job No. W0507 25 003

RESPONSIBILITY IS LIMITED TO THE STRUCTURAL DESIGN OF THE SHIELDING SYSTEM PREPARED BY PENNONI ASSOCIATES, INC.

VeriShield Mevion S250 Cyclotron Vault & 25" Bi-Parting Door  
Auburn University - Proton Radiation Testing Facility  
Lot 4, Mark C. Smith Drive  
Huntsville, Alabama 35801  
United States of America

DRAWING ISSUE LOG

#	ISSUE TITLE	Date
1	Review Set	03/21/2025

VERITAS PROJECT TEAM

SALES REP: Greg Shearer  
PHYSICIST: El Hassane Bentefour  
DESIGNER: Jay DiRaimondo  
PROJECT MANAGER: Susan Heid

VERITAS PROJECT INFORMATION

PROJECT # 24-136-5195  
PROSPECT # 5195-01  
PHYSICS REPORT: BP25 (3060-501)  
MACHINE: Mevion S250  
MACHINE ENERGY:

DRAWING TITLE

BEARING PLATE  
PLAN

DRAWING NUMBER

XS-210

PRELIMINARY - NOT FOR CONSTRUCTION




ANCHOR, CONNECTION, & SUPPORT CHART


ITEM	DIAMETER	LENGTH	MIN. EMBED	DESCRIPTION (USE / LOCATION)	NOTES
HILTI HAS E-B	1" [25.4 mm]	16" [406.4 mm]	12" [304.8 mm]	<i>BI-PART &amp; SLIDING</i> DOOR FRAME BASE PLATE ANCHORS	UTILIZE APPROVED INJECTION ADHESIVE
HILTI HIT-Z	3/4" [19.05 mm]	9 3/4" [247.65 mm]	6" [152.4 mm]	<i>BI-PART &amp; SLIDING</i> DOOR FRAME WALL TIE-BACK ANCHORS	UTILIZE APPROVED INJECTION ADHESIVE
NELSON H4L	5/8" [15.875 mm]	4" [101.6 mm]	NOT APPLICABLE	WELD TO BEARING PLATES & LINTELS	SPACING & QUANTITY PER DETAILS ON XS-50x SHEET(S)
REBAR	VARIES, AS REQ'D	VARIES, AS REQ'D	6" [152.4 mm]	REINFORCING CELLS, 6" MIN. EMBED (SLAB)	SEE XS-110 WALL REINFORCING PLAN FOR REBAR SIZE(S)
HILTI HIT-HY 200(R)	NOT APPLICABLE	NOT APPLICABLE	NOT APPLICABLE	APPROVED INJECTION ADHESIVE (USA)	(R = REGULAR), HOUR AND A HALF CURE TIME

UNLESS NOTED / DETAILED OTHERWISE, ALL HOLES PROVIDED FOR ANCHORS TO BE A MIN. OF 1/16" [1.59mm] LARGER THAN & NO GREATER THAN A MAX. 1/8" [3.175mm] LARGER THAN BOLT DIA.


A Anchor, Connection, & Support Chart  
3/8" = 1'-0"




5 WALL TIE TO BEAM - SECTION DETAIL  
1" = 1'-0"




3 WALL TIE TO BEAM - PLAN DETAIL  
1" = 1'-0"



6 BEAM TO BEARING PLATE DETAIL  
1" = 1'-0"



4 DIAPHRAGM STRAP TO BEAM DETAIL  
1" = 1'-0"



2 Typical Coursing Diagram - Full Layer  
1" = 1'-0"

SEAL

**veritas**  
Medical Solutions  
160 CASSELL RD.  
HARLEYSVILLE, PA 19438  
(484) 901-8928

CONDITIONS OF USE

WHEN THIS DOCUMENT IS SUPPLIED TO EITHER OWNER OR CONTRACTOR, IN EITHER PAPER OR ELECTRONIC FORM, THE SUBSEQUENT USE OF THE INFORMATION CONTAINED ON THE DOCUMENT IS SUBJECT TO THE CONDITIONS OF THE AGREEMENT BETWEEN THE OWNER AND VERITAS AND TO VERITAS COPYRIGHT AND OTHER SUCH RIGHTS IN THIS DOCUMENT. CONTRACTOR MAY MAKE ELECTRONIC FILES OF THIS DOCUMENT AVAILABLE TO SUBCONTRACTORS IN THEIR PREPARATION OF SHOP DRAWINGS. THE PROVISION OF THIS DOCUMENT BY VERITAS SHALL NOT MAKE VERITAS RESPONSIBLE IN ANY WAY FOR ANY ASPECT OF THE SUBCONTRACTORS SHOP DRAWINGS, NOR RELIEVE SUBCONTRACTORS FROM FULL RESPONSIBILITY FOR PREPARATION OF THEIR REQUIRED SHOP DRAWINGS.

Pennoni Associates Inc.  
81 Highland Ave., Suite 230  
Bethlehem, PA 18017  
PAI Job No. W0507 25 003

RESPONSIBILITY IS LIMITED TO THE STRUCTURAL DESIGN OF THE SHIELDING SYSTEM PREPARED BY PENNONI ASSOCIATES, INC.

VeriShield Mevion S250 Cyclotron Vault & 25" Bi-Parting Door  
Auburn University - Proton Radiation Testing Facility  
Lot 4, Mark C. Smith Drive  
Huntsville, Alabama 35801  
United States of America

#	ISSUE TITLE	Date
Review Set		03/21/2025

VERITAS PROJECT TEAM

SALES REP: Greg Shearer  
PHYSICIST: El Hassane Bentefour  
DESIGNER: Jay DiRaimondo  
PROJECT MANAGER: Susan Heid

VERITAS PROJECT INFORMATION

PROJECT # 24-136-5195  
PROSPECT # 5195-01  
PHYSICS REPORT: BP25 (3060-501)  
SHIELDED DOOR(S): BP25 (3060-501)  
MACHINE: Mevion S250  
MACHINE ENERGY:

DRAWING TITLE

STRUCTURAL  
DETAILS

DRAWING NUMBER

XS-300

PRELIMINARY - NOT FOR CONSTRUCTION







